


MS8238B

Digital Multimeter User's Manual



CONTENTS

1. Overview	1
2. Safety Information	1
2.1 Safety Standards.....	1
2.2 Precautions.....	2
2.3 Electrical Symbols	3
3. Description and Usage	4
3.1 Front Panel.....	4
3.2 Display	5
3.3 Using the Meter.....	6
4. Specifications	10
4.1 General Specifications.....	10
4.2 Technical Specifications	11
5. Maintenance	14
5.1 General Maintenance	14
5.2 Replacing the Battery and Fuses	14
5.3 Replacing the Probe	15
6. Accessories	15

1. Overview

WARNING

TO avoid electrical shock or personal injury, please read all safety information, warnings and precautions before using the meter.

The MS8238B is a small, safe and reliable 3 1/2 digit handheld multimeter. This meter can measure AC/DC voltage, AC/DC current, resistance, diode, continuity, battery test and non-contact voltage tests. This tool is ideal for professionals and hobbyists alike.

2. Safety Information

2.1 Safety Standards

The MS8238B meets standards for CAT III 600V, installations and a pollution degree of 2.


- The protection provided by the meter can only be ensured if all safety procedures are strictly followed.
- The safety symbols on the meter are to advise of potential dangerous situations. Caution is required when measuring close to the meter's safety limits.
- Never exceed the protection limit values indicated in the specifications for each range of measurement.

WARNING











The special attention should be paid when using the meter because the improper usage may cause electric shock and damage the meter. The safety measures in common safety regulations and operating instruction should be complied with when using. In order to make fully use of its functions and ensure safe operations please comply with the usage in this section carefully.

2.2 Precautions

- To avoid electrical shock or personal injury, observe and follow all safety precautions
- Check the meter for damage before use. Do not use if any damage is observed.
- Check the test leads for cracks or exposed wires before using the meter. Replace if necessary.
- Ensure the meter works properly by testing a known voltage source first. If not working properly, the protective equipment may be damaged; have the meter serviced before using.
- Never measure voltages that may exceed the protection limit indicated on the meter.
- Always be careful when working with voltages above 60V dc or 30V ac rms. Keep fingers behind the probe barriers when making voltage measurements.
- Make sure the test leads are in the correct input jacks before measurement.
- Do not expose the meter to explosive gas, dust or vapor.
- When connecting the test leads to a measurement circuit, connect the common lead first, then the live lead. Reverse when disconnecting.
- Turn off power to circuit and discharge all capacitors before making resistance, continuity or diode measurements.
- In order to avoid incorrect DC voltage readings, check the circuit for AC voltage first, then put the meter in the appropriate DC voltage range.
- Turn off circuit power and check fuses before connect the leads when measuring current. Turn circuit power on after making connection.
- Never use the meter unless the back cover is in place and fastened securely.

- When the low battery indicator " " is displayed, replace the battery. The accuracy of the meter cannot be guaranteed while the low battery indicator is on.
- Before opening the case, always disconnect test leads from all energized circuits.
- For continued protection against fire, replace fuse only with the specified voltage and current ratings listed in the manual.
- Measure known voltage with the meter to verify that the meter is working properly. If the meter is working abnormally, stop using it immediately. A protective device may be damaged. If there is any doubt, please have the meter inspected by a qualified technician.

2.3 Electrical Symbols


	Important safety information.
	High voltage with danger.
	Ground.
	Double Insulation (Class II safety equipment).
	Fuse must be replaced as per the specification herein.
	Accord with the related EU laws and regulations
	AC (Alternating Current)
	AC (Alternating Current)
	AC & DC (Both direct and Alternating Current)
	Conforms to UL STD. 61010-1, 61010-2-030 and 61010-2-033; Certified to CSA STD. C22.2 NO. 61010-1, 61010-2-030 and IEC STD. 61010-2-033

CAT III : MEASUREMENT CATEGORY III

is applicable to test and measuring circuits connected to the distribution part of the building's low-voltage MAINS installation.


3 Description and Usage

3.1 Front Panel



- 1. LCD display
- 2. Data hold button
- 3. Rotary switch
- 4. 10A input jack
- 5. Common jack
- 6. Input jack
(all functions except current
greater than 200mA)
- 7. Non-contact voltage
(NCV) button
- 8. Non-contact voltage
(NCV) indicator

3.2 Display



- 1. Low battery indicator
- 2. Data hold
- 3. Measurement display
- 4. Polarity indicator

3.3 Using the Meter

3.3.1 Data Hold

The data hold function will hold the current reading on the display.

- Press the “**HOLD**” button to hold the current reading. “**H**” symbol will appear on the display.
- Press the “**HOLD**” button to release the hold.

3.3.2 Non-Contact Voltage Detection (NCV)

Hold the “**NCV**” button down in any mode and the meter will activate the non-contact voltage detection.

- Hold the meter up to a voltage source and the buzzer will sound and the NCV indicator will light up if voltage is detected.
- Release the “**NCV**” button to stop NCV detection.

3.3.3 AC/DC voltage measurement

- Set the rotary switch to the appropriate AC or DC voltage range.
- Connect the red test lead to the input jack and the black lead to the COM jack.
- Connect the leads to the circuit under test and read the measurement on the display. Observe polarity for DC measurements. If “**OL**” is display, it means the measurement has exceeded the current range. Move the rotary switch to a higher range.

Warning

Do not measure voltages higher than 600V DC or AC rms to prevent damage to the meter or personal injury.

3.3.4 AC/DC current measurement

- Turn off power to the circuit. Allow all capacitors to discharge.
- Set the rotary switch to the appropriate AC or DC current range.
- Depending on the current to be measured, connect the red test lead to either the input or 10A jack and the black lead to the COM jack.
- Break the circuit and connect the leads in series with the circuit (black lead on the lower voltage side).
- Turn circuit power on and read the measurement on the display. If “**OL**” is display, it means the measurement has exceeded the current range. Move the rotary switch to a higher range.

Warning

Never measure open-circuit voltages exceeding 250V between the input terminals and ground to prevent injury or damage to the meter.

NOTE

Check fuses before making current measurements, Make sure to use correct input jacks to prevent damage to the meter.

3.3.5 Resistance measurement

- Turn off power to the circuit. Allow all capacitors to discharge.
- Set the rotary switch to the appropriate resistance range.
- Connect the red test lead to the input jack and the black lead to the COM jack.
- Connect the leads to the circuit under test and read the measurement on the display.

Tips for measuring resistance:

- In-circuit resistance is usually different from a resistors rating due to the fact that the meter's test current flows in parallel with the circuit.
- For increased accuracy when measuring low resistances, short the test leads, record the value displayed, then connect the leads to the circuit and subtract the shorted value from the circuit measurement.
- When the leads are disconnected from the circuit under test, "OL" will be displayed on the screen.

Warning

To prevent injury or damage to the meter, turn off power to circuit and discharge all capacitors fully before making resistance measurements.

3.3.6 Continuity measurement

- Turn off power to the circuit. Allow all capacitors to discharge.
- Set the rotary switch to the continuity position.
- Connect the red test lead to the input jack and the black lead to the COM jack.
- Connect the leads to the circuit under test. If the measured resistance is less than 50Ω , the buzzer will sound.

Warning

To prevent injury or damage to the meter, turn off power to circuit and discharge all capacitors fully before making resistance measurements.

3.3.7 Diode test

Turn off power to the circuit. Allow all capacitors to discharge.

- Set the rotary switch to the diode position.
- Connect the red test lead to the input jack and the black lead to the COM jack.
- Connect the red test lead to the anode (+) and the black lead to the cathode (-) of the diode and read the measurement on the display. The meter will display "OL" if the connection is reversed.

Warning

To prevent injury or damage to the meter, turn off power to circuit and discharge all capacitors fully before making resistance measurements.

3.3.8 Battery test


- Set the rotary switch to the appropriate battery test range.
- Connect the red test lead to the input jack and the black lead to the COM jack.
- Connect the red test lead to the positive (+) end and the black lead to the negative (-) end of the battery and read the measurement on the display.

Warning

To prevent injury or damage to the meter, do not connect the meter to a battery with a voltage rating exceeding 60V AC or 30V DC

4. Specifications

4.1 General Specifications

Function	Range
Safety Rating	CAT III 600V; pollution degree: II
Operating Altitude	<2000m
Operating Temperature/ Humidity	0~40°C, <80% RH
Storage Temperature/ Humidity	-10~60°C, <70% RH, remove battery
Max. Input between terminals and earth ground	600V DC or AC rms
Fuse Protection	10A range: F1:FF 10A H 600V mA range: F2:FF 400mA H 600V
Sample Rate	Approx. 3 times/sec.
Display	3 ½ digit LCD display
Overload Indication	Display shows "OL"
Low Battery Indication	When battery voltage drops below normal operating voltage, "  " is shown on the display
Polarity Indication	Display automatically displays "-"
Power Supply	DC 9V, NEDA 1604 or 6F22
Size(LxWxH)	148x 73.5x 50mm
weight	about 232g

4.2 Technical Specifications

Accuracy: \pm (% of reading + digits) at 18°C~28°C with a relative humidity of <80%; guaranteed for a period of one year.

4.2.1 DC Voltage

Measuring range	Resolution	Accuracy
200mV	0.1mV	\pm (0.5% of reading + 2 digits)
2V	0.001V	
20V	0.01V	
200V	0.1V	\pm (0.8% of reading + 5 digits)
600V	1V	

Max. input voltage: 600V DC or AC rms.

4.2.2 AC Voltage

Measuring range	Resolution	Accuracy
200V	0.1V	\pm (1.0% of reading + 5 digits)
600V	1V	

Max. input voltage: 600V DC or AC rms.


Frequency Response: 40~400Hz, sine wave rms
(avg. response)

4.2.3 Resistance

Measuring range	Resolution	Accuracy
200Ω	0.1Ω	\pm (0.8% of reading + 4 digits)
2kΩ	0.001kΩ	
20kΩ	0.01kΩ	
200kΩ	0.1kΩ	
2MΩ	0.001MΩ	


Overload protection: 250V DC or AC (RMS)

4.2.4 Diode Test

Function	Resolution	Description
Diode Test 	0.001V	Forward DC current: 1mA Reverse DC voltage: 2.9V Display shows forward voltage drop

Overload protection: 250V DC or AC (RMS)

4.2.5 Continuity

Function	Description	Description
	If measured resistance is less than 50Ω, buzzer will sound	Open circuit voltage: 2.9V

Overload protection: 250V DC or AC (RMS)

4.2.6 DC Current

Measuring range	Resolution	Accuracy
200mA	0.1mA	±(0.8% of reading +3 digits)
10A	10mA	±(1.2% of reading +3 digits)

Overload protection:

mA jack: FF400mA H 600V fuse

10A jack: FF10A H 600V fuse

Max input current: mA jack: 200mA DC

10A jack: 10A DC

When measuring current exceeding 2A, do not measure for longer than 2 minutes continuously. Wait 10 minutes to continue measurement.

4.2.7 AC Current

Measuring range	Resolution	Accuracy
200mA	0.1mA	±(1.0% of reading +3 digits)
10A	10mA	±(1.5% of reading +3 digits)

Overload protection:

mA jack: FF400mA H 600V fuse

10A jack: FF10A H 600V fuse

Max input current: mA jack: 200mA AC rms

10A jack: 10A AC rms

When measuring current exceeding 2A, do not measure for longer than 2 minutes continuously. Wait 10 minutes to continue measurement.

4.2.8 Battery Test

Position	Resolution	Accuracy
12V	0.01V	±(0.8% of reading +7 digits)
9V	0.01V	±(0.8% of reading +7digits)
1.5V	0.001V	±(3.0% of reading +5digits)

Overload protection: F400mA H 600V fuse

4.2.9 NCV Test

- Hold down the NCV button and move the NCV sensor at the top of the unit next to the object being tested.
- When voltage is detected (>110V AC rms) the buzzer will sound and the NCV indicator will flash.

Note:

- Even if the indicator doesn't go off, voltage may still exist. Do not use NCV detection as the sole determination of a lack of voltage present in a conductor. Detection could be impaired by socket design, insulation, etc.
- When measuring voltage through input jacks, NCV indicator may light up due to induced voltage.
- External environmental interference could cause false NCV indications.

5. Maintenance**5.1 General Maintenance**

This section provides basic information on maintaining the meter, such as replacing fuses and the battery. Only experienced and authorized personnel should make repairs to the meter.



To avoid injury or damage to the meter, do not allow moisture inside the case and remove test leads before opening battery cover.

- Use a damp cloth to regularly clean the outside of the meter. Do not use abrasives or chemical solvents. Dirty or damp input jack can adversely affect readings.
- To clean input jacks, follow the following steps:
 1. Turn off the instrument and remove the test leads.
 2. Clear any dirt or other particles on the input jacks.
 3. Use a cotton ball/swab with a lubricant (i.e. WD-40) to clean off the contacts of the input jacks.
 4. Use a separate cotton ball/swab for each jack to prevent cross-contamination.

5.2 Replacing the Battery and Fuses

1. Under normal conditions, it is unnecessary to replace the fuse. Don't replace it until the probes are unplugged and the power is shut down. Take out the two screws of the rear cover to remove the housing.
2. The specification of the fuse is:
F1 F 10A H 600V, F2 F 400mA H 600V
The replacement should be of the same specification.
3. The battery for this multimeter is 9V NEDA 1604 or 6F22.
The replacement should be of the same specification.
4. Don't put the instrument into use until the rear cover is screwed after replacing battery or fuse.



To avoid electric shock, make sure the probes are disconnected from the measured circuit before removing the rear cover. Make sure the rear cover is tightly screwed before using the instrument.

5.3 Replacing the Probe

If insulation on probe is damaged, replace it.



Use meet EN 61010-031 standard, rated CAT III 600V, 10A or better probe.

6. Accessories

- | | |
|-----------------|------|
| • Test Leads | 1set |
| • Package | 1pcs |
| • 9V Battery | 1pcs |
| • User's Manual | 1pcs |



R-00-05-1049